

# Quick start guide

Get started with your Beetronics all-in-one display



### **Getting started**


To get started, unpack the box and verify that the following content is included.

Clamps | 8x

A. All-in-one display



B. Mounting kit



D. Mounting brackets

E. Cable clips

F. Quickstart




Screws | 8x



Brackets | 8x

Clips | 4x

#### Connecting the hardware



- 1. On/OFF power button
- 2. Mounting brackets fixation
- 3. COM 1 (supports RS232)
- 4. COM 2 (supports RS232/RS485/RS422)
- 5. AUX/Audio in
- 6. AUX/Audio out
- 7. USB 2.0 port x 2
- 8. RJ45 LAN port (1000 mb/s)
- **9.** USBA 3.0 x 2
- 10. VGA output
- 11. HDMI output
- 12. 12V DC port

## **Device quickstart**

- 1. The AIO comes with Ubuntu pre-installed and is set to turn on automatically when connected to power, making it immediately ready for use via the touch interface.
- 2. (Optional) Connect ethernet cable to the RJ45 LAN port (9).
- 3. (Optional) Connect external speakers or headphones to the AUX output (7) and microphone to the AUX input (6).
- 4. (Optional) Connect a mouse, keyboard or other PC peripherals to the USB ports (8, 10).
- 5. (Optional) Connect additional displays via VGA (11) or HDMI (12).

#### **Panel mounting**

- 1. Place the display into the designated cut-out area, ensuring the edges of the display align precisely with the edges of the cut-out. Make sure the cut-out is neither too small nor too large and account for the thickness of the display.
- 2. Attach the fixed screws from the back of the panel onto the screw interface on the side of the display.
- **3.** Tighten each screw firmly so that the all-in-one display is securely attached to the wall or panel.

